


Assembly Instructions




Kit includes: banner stand & carry bag




Open up the legs on the stand, and place upright with supporting leg leading behind the system.




Slide the supporting leg towards or away from the front lower legs to create stability.



Adjust the height of the eyelet pip on each leg by opening up the lever on the fixing, moving to desired position and then closing the lever to secure.



Hook each eyelet in the corners of the graphic over the pip on each leg. Steps 2 and 3 may need to be repeated to bring the banner into tension.



Other products in our banner range include:



Pacific

Single sided roller cassette banner with stabilising foot. Choice of 800mm or 1000mm width.



Orient

Stylish single sided roller cassette banner, with a choice of 800mm or 1000mm widths.



Barracuda

Single sided roller cassette banner. Lightweight, strong and extremely stylish with retractable internal roller banner making presentation quick and effective.